

DV MINI DV & HI-8CAMCORDER REFERENCE CHART

CAMERA MODEL	CAMERA CASE	CAMERA + ACC. CASE	LARGER CASE OPTION	CAMERA BACKPACK	RAIN COVER
CANON: ELURA 70, 40MC, 20MC, 10, 2MC, 2	EC-01	C-56 / EC-02	C-58	NONE	NONE
CANON: ZR 90, 85, 90, 70MC, 65MC, 60, 50MC, 45MC, 40, 30MC, 25MC, 20, 10	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
CANON: OPTURA XI, 200MC, 100MC, 20, 10, P1	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
CANON: ES 8200, 8100, 7000, 6500, 4000, 420V, 410V, 400V, 190, 65, 60, 55, 50	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
CANON: XM-2, GL-2, XM-1, GL-1	EXO-12 / CCC-101	SHELL-03 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-13
CANON: XL2, XL1, XL1S	EXO-33	CCC-10	CCC-1	BP-502 / GRIZZLY-3	CRC-11 / RC-10
HITACHI: DZ-MV100A	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
HITACHI: VMD 975LA, 965LA, 875LA, 865LA	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
HITACHI: VMH 955LA, 855LA, 765LA, 755LA, 675LA, 665LA, 650A	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
HITACHI: VME 565LA, 555LA	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR DV3U	EC-01	C-56 / EC-02	C-58	NONE	NONE
JVC: GR DX307, DX300, DX97, DX95, DX77, DX75	EC-01	C-56 / EC-02	C-58	NONE	NONE
JVC: GR DVP9, DVP7U, DVP3U	EC-01	C-56 / EC-02	C-58	NONE	NONE
JVC: GR DVM90U, DVM80U, DVM75U, DVM70U, DVM55U, DVM50U, DVM5U	EC-01	C-56 / EC-02	C-58	NONE	NONE
JVC: GR D30, D33, D70, D72, D90, D93, D200, D230	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVL9800U, DVL9500U, DVL9000	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVL920, DVL915U, DVL820, DVL815U, DVL805U, DVL725U, DVL720U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVL520U, DVL510U, DVL507U, DVL505U, DVL500U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVL310U, DVL307U, DVL300U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVM96U, DVM76U, DV2000U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR DVX707A, DVX507A	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
JVC: GR AX970, AX960, AX930	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR AX890, AX880, AX851, AX850, AX841, AX840	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR AX760, AX750, AX730, AX720	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR AX640, AX240, AXM230U, AXM225	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR DV3000, DV800, DV500	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR DVA1U	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR DVL120, DVL320	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR DVF31, DVF21, DVF11, DVF10U	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: SX960U	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: GR SXM930U, SXM730U, SXM330U	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
JVC: JY-HD10U	SHELL-03	CC-193 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-14
JVC: JY-VS200	CC-191 / CCC-101	SHELL-03 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-13
JVC: GR DV300, DV300U, DV300E, DV301E	SHELL-03	CC-193 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-14
PANASONIC: SV-AV100	P-32	P-34	C-56 / EC-01	NONE	NONE
PANASONIC: SV AV50A, AV50S	P-34	C-56 / EC-01	C-58 / EC-02	NONE	NONE
PANASONIC: PV GS210, GS200, GS120, GS70, GS55, GS50	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
PANASONIC: PV GS15, GS14, GS12, GS9	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
PANASONIC: PV DC352, DC252, DC152	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
PANASONIC: PV DV73, DV70, DV53	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
PANASONIC: VDR M30, M20, M10, PV VM202	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
PANASONIC: AG E250U, E230U, EZ1	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV DV953, DV952, DV951, DV950, DV901, DV852, DV851, DV800	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV DV710, DV702, DV701, DV601, DV600, DV402, DV401, DV400	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV DV351, DV203, DV202, DV201, DV103, DV102, DV101, DV100	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV DV52, DV51, D300, D301	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV L850, L751, L750, L652, L651, L650, L601	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: PV L552, L551, L550, L501, L454, L453, L452, L353, L352, L354	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
PANASONIC: AG DVX100A, DVC80	SHELL-03	CC-193 / CCC-103	EXO-33 / MC-61	PANDA-402 / HB-207	CRC-14
PANASONIC: AG DVC30	EXO-12	SHELL-03 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-13 / CRC-14
PANASONIC: AG DVC15, DVC10, DVC7, DVC60	EXO-33 / MC-61	CCC-10	CCC-1	BP-502 / GRIZZLY-2	RC-10
SAMSUNG: SC L520, L610, L650	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
SAMSUNG: SC W62, M51	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
SHARP: VL A110U, A45, A10U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SHARP: VL AH160U, AH260, AH150U, AH130U, AH60U, AH50U, AH30U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SHARP: VL E785U, E780U, E685U, E680U, E630U, E610U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SHARP: VL FD1U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SHARP: VL SD20U	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SHARP: VL WD650U, WD450U, WD255U, WD250U	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
SONY: DCR IP1, IP7BT, IP5	EC-01	C-56 / EC-02	C-58	NONE	NONE
SONY: DCR PC5, PC3, PC1	EC-01	C-56 / EC-02	C-58	NONE	NONE
SONY: DCR DVD100, DVD101, DVD200, DVD201 DCM M1	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR IP220, IP65	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR PC330, PC300K, PC120BT	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR PC109, PC105, PC101, PC100, PC110	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR PC9	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV460, TRV328, TRV260, TRV128	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV80, TRV70, TRV50TRV39, TRV38, TRV33, TRV30	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV27, TRV25, TRV22	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV19, TRV18, TRV17, TRV11	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV6	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR HC85, HC65, HC40, HC30, HC20	C-56 / EC-02	C-58	C-59 / EXO-7 / W-92	NONE	NONE
SONY: DCR TRV350, TRV318, TRV250	C-58	C-59 / EXO-7 / W-92	EXO-12	NONE	NONE
SONY: DCR TR818, TR87	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
SONY: DCR TRV950, TRV900	C-58	C-59 / EXO-7 / W-92	EXO-12	R-103 / R-102	CRC-18
SONY: DCR TRV840, TRV830, TRV820	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV740, TRV730, TRV720	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV608	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV530, TRV520, TRV517	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV340, TRV330, TRV320, TRV310, TRV308	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV240, TRV230	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV140, TRV130, TRV108	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV98, TRV88, TRV87	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DCR TRV68, TRV67, TRV58, TRV57, TRV37	EXO-7 / W-92	EXO-12	CC-191 / CCC-101	R-103 / R-102	CRC-18
SONY: DSR PDX-10, 10P	EXO-12	SHELL-03 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-13
SONY: DCR VX1000, PD-100, PD-100A, EVO-9100	CC-191 / CCC-101	SHELL-03	CC-193 / CCC-103	R-103 / R-102	CRC-13
SONY: DCR VX2100, VX2000,	SHELL-03	CC-193 / CCC-103	EXO-33 / MC-61	R-103/102/PANDA-402	CRC-14
SONY: DSR PD-170, 170P, 150, 150P	SHELL-03	CC-193 / CCC-103	EXO-33 / MC-61	PANDA-402 / HB-207	CRC-14
SONY: HDR Z1, FX1 (HDV)	CCC-103	CC-193	MC-61	HB-207 / BP-502	CRC-15

Find our most updated chart at www.kata-bags.com

Development & production by KATA Ltd.
 POB 4253 Jerusalem , Israel 91042
 Tel: + 972-2-5388844
 Fax: + 972-2-5388845
www.kata-bags.com
 Info: technical@kata-bags.com
 Sales: video@kata-bags.com



KATA. A SIMPLE CASE OF BETTER DESIGN.