



STUDIO RAIN COVER

RAIN COVER FOR OUTDOOR BROADCASTING



Extra length protects camera and tripod in wind and rain.
Extra width allows complete freedom of movement even when fastened to tripod in windy conditions



STUDIO RC

ORDER CODE KT / VA-862				Wt. 8.31 lbs 3.77 Kg
---------------------------	--	--	--	-------------------------


The STUDIO RC is a comprehensive rain cover that provides protection for the entire photographic gear: Camera, tuning handles, zoom control, follow focus and tripod. Once a studio camera is harnessed into an outdoor production it will spend long stretches of time exposed to the natural elements, more than ordinary ENG cameras, because it will be left outside even when not in use. The STUDIO RC provides long term protection against rain, moisture dust and scratches. And can also be used in large studio productions to protect the camera. The STUDIO RC is suitable for a variety of studio cameras, tripods and accessories.

MATERIALS

- Crystal clear vinyl window
- High density nylon fabric, treated with 3 layers of PU component coating
- Fastex-ITW® nylon or acetal buckles

INSTALLING STUDIO RC

1. Unfold RC from mesh pocket.
2. Insert the rear end of the view finder into the transparent cap.
3. Tighten the monitor hood around the front of the view finder.
4. Fasten handle, flap and middle zippers.
5. Stretch the cover over the camera and tighten the lens hood around the rim of the lens.
6. Fasten main zipper .



An integral mesh accessory pocket provides an easy storage solution for the Studio Rain Cover when not in use

Development & production by KATA Ltd.
POB 4253 Jerusalem , Israel 91042
Tel: +972-2-5388844
Fax: + 972-2-5388845
www.kata-bags.com
Info: technical@kata-bags.com
Sales: video@kata-bags.com



KATA. A SIMPLE CASE OF BETTER DESIGN.