Bedienungsanleitung

ZOE-DVX

Wide

Wenn der Knopf „Wide“ gedrückt wird, läuft der Zoom mit konstanter Geschwindigkeit in Richtung Weitwinkelbereich. Die Geschwindigkeit des Zooms lässt sich mittels Drehrad, siehe links vom Gehäuse, für die Zoomrichtung vorab separat einstellen.

Tele

Wenn der Knopf „Tele“ gedrückt wird, läuft der Zoom mit konstanter Geschwindigkeit in Richtung Telebereich. Die Geschwindigkeit des Zooms lässt sich mittels Drehrad, siehe rechts vom Gehäuse, für die Zoomrichtung vorab separat einstellen.

RECORD

Einzelklick:
Startet bzw. beendet die Aufnahme, wenn sich der Hauptschalter der Kamera auf Position "Camera" befindet.

PZB® PreciseZoomButtons

Parallel zu der klassischen Zoomwippe wird das Zoomen durch drücken der zwei Tasten Tele und Wide gesteuert.

Hinweis: Mit Beschädigung der Klebefolie bzw. der Siegel erlischt jeglicher Garantieanspruch.

Broadcast Engineering Dipl. Ing. Pierre Boudard
Höglwörther Str. 350 D-81379 München
Tel. +49 89/ 27 81 82 82 Fax. +49 89/ 27 81 82 81
Email Info@bebob.de

Operating instructions

ZOE-DVX

Wide

PSZ© knob for Wide-Angle Zoom

Tele

PSZ© knob for Tele-Zoom

Speed wheel for Wide-Angle Zoom:
Pre-Adjustment of the PSZ© Wide-Angle Zoom Speed. Please see herefore the direction of arrow. If you turn down the wheel, the Wide-Angle Zoom Speed becomes faster and turn up the wheel the Wide-Angle Zoom speed becomes slower.

RECORD

Single click:
Starts or ends the recording when the main switch on the camcorder is set to "Camera".

Speed wheel for Tele-Zoom:

Pre-Adjustment of the PSZ© Tele-Zoom Speed. Please see herefore the direction of arrow. If you turn down the wheel, the Tele-Zoom Speed becomes faster and turn up the wheel the Tele-Zoom speed becomes slower.

PZB© PreciseZoomButtons

As with most of the cameras, it is sometimes difficult, with the AG-DVX80 and AG-DVX100 to hit the exact position of the rocker switch where the zoom starts. To make it easy in such situations where it is needed, we developed the PSZ© technology: Adjust the speed you need with the speed wheel. Press the button an the zoom starts in the moment you did press the button. It is as easy and precise.

Note: Any damage to the adhesive labels voids all warranty provisions.

Broadcast Engineering Dipl. Ing. Pierre Boudard
Höglwörther Str. 350 D-81379 München
Tel. +49 89/ 27 81 82 82 Fax. +49 89/ 27 81 82 81
Email Info@bebob.de